



Personal Protective Equipment (PPE)


The following PPE is recommended to be worn during the dispensing of chemicals and changing of any chemical containers.



Apron




Gloves




Goggles



The following PPE is recommended to be worn during cleaning.



Apron



Gloves

Clean Pro+ Product	Dosing	Application
<p>* Heavy Duty Cleaner Degreaser</p> 	<p>30 – 90ml per trigger spray 90 ml per 5 litre bucket</p>	

Cleaning Method

- 1 Empty any debris from drains and traps into bin.
- 2 Remove any traps and channel covers.
- 3 Using a floorbrush, clean all surfaces of drain channels and traps with Heavy Duty Cleaner Degreaser solution; changing solution as necessary .
- 4 Replace any removed traps and channel covers.
- 5 Allow to air dry.

* This product is also available as a 1 litre concentrate and a 1 litre ready to use.