


Personal Protective Equipment (PPE)





Important

Use with great care on items containing soft metals such as zinc and copper.

Contact with certain plastics may result in corrosion stress cracking.

For machines with a washwater reservoir please ensure all washwater is emptied out and reservoir is re-filled with fresh water before commencing the descaling process.

Clean Pro+ Product	Dosing	Application
Scale Remover	10 - 50 ml per litre of water	

Cleaning Method

- To descale a dishwasher, add the scale remover to the wash water.
- Allow the machine to run on a normal wash cycle (up to 70°C).
- Once descaling method complete, the dishwasher is to be fully drained down and rinsed with fresh water.
- To descale bains-marie and other similar equipment, place equipment into scale remover solution and leave in contact for approximately 15 minutes .
- **S** Rinse with fresh, clean water to ensure all debris is removed.