



Personal Protective Equipment (PPE)


The following PPE is recommended to be worn during the dispensing of chemicals and changing of any chemical containers.



Apron




Gloves




Goggles

The following PPE is recommended to be worn during cleaning.



Apron



Gloves

Clean Pro+ Product	Dosing	Application	
<p>* Kitchen Cleaner</p> 	30 – 60 ml per trigger spray		
<p>* Detergent Disinfectant</p> 	30 ml per trigger spray		
<p>Fast Acting Antibacterial Cleaner & Disinfectant</p> 	Ready to use		

Cleaning Method

- 1 Run the glass washer empty cycle. Remove any filters, traps and wash arms as necessary.
- 2 Clean traps, filters and wash arms by soaking and scrubbing in Kitchen Cleaner solution.
- 3 Spray glasswasher inside and out with Kitchen Cleaner solution paying particular attention to the edges and corners where soiling tends to accumulate.
- 4 Wipe with cloth and scrub as necessary.
- 5 Replace traps, filters and wash arms.
- 6 Spray all cleaned surfaces with a fine mist of Detergent Disinfectant or Fast Acting Antibacterial Cleaner & Disinfectant solution.
- 7 Allow to air dry.

* These products are also available as a 1 litre concentrate and a 1 litre ready to use.